



**Information Requirements of COMMISSION REGULATION (EC) No 1275/2008 amended by
COMMISSION REGULATION (EU) No 801/2013 measured by EN50564**

Guidance on how to activate or deactivate wireless network ports	Push "FN" key and the Function key with antenna mark ( "F8" or "F12") at a time
--	---


Model name	Model No. / Part No.	Power Consumption Modes					Time
		standby mode without information /status display	standby mode with information /status display	off mode	networked standby mode	networked standby mode all ports connected/ activated	default time to switch to standby mode
		[Watt]					[Minutes]
DYNABOOK PORTÉGÉ A30-E	PSZ12E-***	n.a.	n.a.	0,4	0,8	n.a.	15
DYNABOOK PORTÉGÉ R30-E	PSZ10E-***	n.a.	n.a.	0,4	0,8	n.a.	15
DYNABOOK PORTÉGÉ X30-F	PUR31E-***	n.a.	n.a.	0,3	n.a.	n.a.	15
DYNABOOK PORTEGE X30L-G	PUZ20*	n.a.	n.a.	0,3	0,7	n.a.	15
DYNABOOK PORTEGE X30L-G	PUZ22*	n.a.	n.a.	0,3	0,7	n.a.	15
DYNABOOK Satellite Pro L40-G	PJA11-***	n.a.	n.a.	0,2	0,4	0,4	15
DYNABOOK Satellite Pro L50-G	PBS10*-*****	n.a.	n.a.	0,2	0,5	0,5	15
DYNABOOK Satellite Pro L50-G	PBS12*-*****	n.a.	n.a.	0,2	0,5	0,5	15
DYNABOOK Satellite Pro L50-G	PBS22*-*****	n.a.	n.a.	0,2	0,5	0,5	15
DYNABOOK Satellite Pro L50-J	PBS42-***	n.a.	n.a.	0,2	0,6	0,6	4
DYNABOOK TECRA A40E	PMZ10***	n.a.	n.a.	0,4	0,8	0,8	15
DYNABOOK TECRA A40E	PMZ12***	n.a.	n.a.	0,4	0,8	0,8	15
DYNABOOK TECRA A40-G	PMZ20***	n.a.	n.a.	0,3	0,7	0,7	15
DYNABOOK TECRA A40-G	PMZ21***	n.a.	n.a.	0,3	0,7	0,7	15
DYNABOOK TECRA A40-G	PMZ22***	n.a.	n.a.	0,3	0,7	0,7	15
DYNABOOK TECRA X40-F	PMR31E-***	n.a.	n.a.	0,3	n.a.	n.a.	15
DYNABOOK TECRA X50-F	PLR31***	n.a.	n.a.	0,3	n.a.	n.a.	15
DYNABOOK TECRA X50-F	PLR33***	n.a.	n.a.	0,3	n.a.	n.a.	15
KIRA-100	PSU8SE -***	0,3	0,3	2,6	0,6	0,6	15
KIRA-107	PSUC2E -***	0,1	n.a.	0,1	0,4	0,4	15
KIRA-108	PSUC1E -***	0,1	n.a.	0,1	0,4	0,4	15
PORTÉGÉ A30-C	PT363E-***	0,2	n.a.	0,2	0,8	0,8	15
PORTÉGÉ A30-C	PT365E-***	0,2	n.a.	0,2	0,8	0,8	15
PORTÉGÉ A30-D	PT383E-***	0,3	n.a.	0,2	0,4	0,4	15
PORTÉGÉ A30-D	PT385E-***	0,3	n.a.	0,2	0,4	0,4	15
PORTÉGÉ A30t-C	PT365E-***	0,2	n.a.	0,2	0,8	0,8	15
PORTÉGÉ R30-A	PT341E-***	0,2	n.a.	0,2	0,7	0,7	15
PORTÉGÉ R30-A	PT343E -***	0,2	n.a.	0,2	0,7	0,7	15
PORTÉGÉ WT20-C	PT16CE-***	0,2	n.a.	0,2	0,4	0,4	15
PORTÉGÉ WT20-C	PT16DE-***	0,2	n.a.	0,2	0,4	0,4	15
PORTÉGÉ X20W-D	PRT12E-***	n.a.	n.a.	0,5	n.a.	n.a.	15
PORTÉGÉ X20W-D	PRT13E-***	n.a.	n.a.	0,5	n.a.	n.a.	15
PORTÉGÉ X20W-E	PRT22E-***	n.a.	n.a.	0,5	n.a.	n.a.	15
PORTÉGÉ X20W-E	PRT23E-***	n.a.	n.a.	0,5	n.a.	n.a.	15
PORTÉGÉ X30-D	PT272E-***	n.a.	n.a.	0,5	n.a.	n.a.	15
PORTÉGÉ X30-D	PT274E-***	n.a.	n.a.	0,5	n.a.	n.a.	15
PORTÉGÉ X30-E	PT282E-***	n.a.	n.a.	0,5	n.a.	n.a.	15
PORTÉGÉ X30-E	PT284E-***	n.a.	n.a.	0,5	n.a.	n.a.	15
PORTÉGÉ X30W-J	PDA13-***	n.a.	n.a.	0,4	0,9	0,9	15
PORTÉGÉ X30L-J	PCR12-***	n.a.	n.a.	0,4	0,9	0,9	15
PORTÉGÉ X30T-E	PT17AE-***	n.a.	n.a.	0,3	n.a.	n.a.	15
PORTÉGÉ X30T-E	PT17CE-***	n.a.	n.a.	0,3	n.a.	n.a.	15
PORTÉGÉ X30T-E	PT17DE-***	n.a.	n.a.	0,3	n.a.	n.a.	15

Guidance on how to activate or deactivate wireless network ports	Push "FN" key and the Function key with antenna mark ("F8" or "F12") at a time
--	--


Model name	Model No. / Part No.	Power Consumption Modes					Time
		standby mode without information /status display	standby mode with information /status display	off mode	networked standby mode	networked standby mode all ports connected/ activated	default time to switch to standby mode
		[Watt]					[Minutes]
PORTÉGÉ X40-J	PPH13-***	n.a.	n.a.	0,4	0,9	0,9	15
PORTÉGÉ Z20t-B	PT15AE-***	0,3	n.a.	0,3	0,5	0,5	15
PORTÉGÉ Z20t-B	PT15BE-***	0,3	n.a.	0,3	0,5	0,5	15
PORTÉGÉ Z20t-C	PT16AE-***	0,3	n.a.	0,3	0,5	0,5	15
PORTÉGÉ Z20t-C	PT16BE-***	0,3	n.a.	0,3	0,5	0,5	15
PORTÉGÉ Z30-A	PT241E-***	0,3	n.a.	0,2	0,7	0,7	15
PORTÉGÉ Z30-A	PT243E-***	0,3	n.a.	0,2	0,7	0,7	15
PORTÉGÉ Z30-B	PT251E-***	0,2	n.a.	0,2	0,7	0,7	15
PORTÉGÉ Z30-B	PT253E-***	0,2	n.a.	0,2	0,7	0,7	15
PORTÉGÉ Z30-C	PT261E-***	0,2	n.a.	0,2	0,8	0,8	15
PORTÉGÉ Z30-C	PT263E-***	0,2	n.a.	0,2	0,8	0,8	15
PORTÉGÉ Z30-E	PT291E-***	n.a.	n.a.	0,1	0,6	0,6	15
PORTÉGÉ Z30-E	PT293E-***	n.a.	n.a.	0,1	0,6	0,6	15
PORTÉGÉ Z30-E	PT294E-***	n.a.	n.a.	0,1	0,6	n.a.	15
PORTÉGÉ Z30t-A	PT24AE-***	0,3	n.a.	0,2	0,7	0,7	15
PORTÉGÉ Z30t-A	PT24CE-***	0,3	n.a.	0,2	0,7	0,7	15
PORTÉGÉ Z30t-B	PT251E-***	0,2	n.a.	0,2	0,7	0,7	15
PORTÉGÉ Z30t-B	PT253E-***	0,2	n.a.	0,2	0,7	0,7	15
PORTÉGÉ Z30t-C	PT261E-***	0,2	n.a.	0,2	0,8	0,8	15
PORTÉGÉ Z30t-C	PT263E-***	0,2	n.a.	0,2	0,8	0,8	15
QOSMIO X70-B	PSPPE-***	0,4	n.a.	0,4	0,8	0,8	15
SATELLITE C40-C	PSCRJE-***	0,5	n.a.	0,5	0,5	0,5	15
SATELLITE C40-C	PSCRLE-***	0,5	n.a.	0,5	0,5	0,5	15
SATELLITE C40D-C	PSCRNE-***	0,2	n.a.	0,2	1,0	1,0	15
SATELLITE C50-B	PSCLUE-***	0,3	n.a.	0,3	0,9	0,9	15
SATELLITE C50-B	PSCLWE-***	0,3	n.a.	0,3	0,9	0,9	15
SATELLITE C50-B	PSCMLE-***	0,4	n.a.	0,4	0,7	0,7	15
SATELLITE C50-B	PSCMNE-***	0,4	n.a.	0,4	0,7	0,7	15
SATELLITE C50-C	PSCPSE-***	0,4	0,4	0,4	5,7	5,7	30
SATELLITE C50-C	PSCPTE-***	0,4	0,4	0,4	5,7	5,7	30
SATELLITE C50D-B	PSCN4E-***	0,4	n.a.	0,4	1,1	1,1	15
SATELLITE C50D-B	PSCN5E-***	0,4	n.a.	0,4	1,1	1,1	15
SATELLITE C50Dt-B	PSCN6E-***	0,4	n.a.	0,4	1,1	1,1	15
SATELLITE C50t-B	PSCMQE-***	0,4	n.a.	0,4	0,7	0,7	15
SATELLITE C55-C	PSCP2E-***	0,4	0,4	0,4	4,1	4,1	30
SATELLITE C55-C	PSCP6E-***	0,4	0,4	0,4	3,7	3,7	30
SATELLITE C55-C	PSCP7E-***	0,4	0,4	0,4	3,7	3,7	30
SATELLITE C55-C	PSCP8E-***	0,3	0,3	0,3	4,0	4,0	30
SATELLITE C55-C	PSCPBE-***	0,3	0,3	0,3	4,0	4,0	30
SATELLITE C55-C	PSCPEE-***	0,4	0,4	0,3	3,8	3,8	30
SATELLITE C55-C	PSCPFE-***	0,4	0,4	0,3	3,8	3,8	30
SATELLITE C55-C	PSCPJE-***	0,5	0,5	0,3	4,5	4,5	30
SATELLITE C55-C	PSCPKE-***	0,5	0,5	0,3	4,5	4,5	30
SATELLITE C55-C	PSCPNE-***	0,5	0,5	0,4	3,8	3,8	30
SATELLITE C55-C	PSCPPE-***	0,5	0,5	0,4	3,8	3,8	30
SATELLITE C55D-C	PSCQEE-***	0,4	0,4	0,3	4,8	4,8	30
SATELLITE C55D-C	PSCQJE-***	0,5	0,5	0,3	5,9	5,9	30

Guidance on how to activate or deactivate wireless network ports	Push "FN" key and the Function key with antenna mark ( , "F8" or "F12") at a time
--	---

Model name	Model No. / Part No.	Power Consumption Modes					Time
		standby mode without information /status display	standby mode with information /status display	off mode	networked standby mode	networked standby mode all ports connected/ activated	default time to switch to standby mode
		[Watt]					[Minutes]
SATELLITE C70-C	PSCSAE-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE C70-C	PSCSEE-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE C70-C	PSCSJE-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE C70-C	PSCSLE-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE C70-C	PSCSNE-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE C70-C	PSCSSE-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE C70D-B	PSCLEE-***	0,3	n.a.	0,3	0,9	0,9	15
SATELLITE C70D-C	PSCSWE-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE CL10-B	PSKVEE-***	n.a.	n.a.	0,4	0,5	0,5	15
SATELLITE CL10-C	PSKV2E-***	n.a.	n.a.	0,4	0,5	0,5	15
SATELLITE CL10W-B	PSKVQE-***	n.a.	n.a.	0,4	0,5	0,5	15
SATELLITE CLICK Mini L9W-B	PDW0FE-***	0,2	0,2	0,2	4,7	4,7	30
SATELLITE L10-B	PSKVG E-***	n.a.	n.a.	0,4	0,5	0,5	15
SATELLITE L10-C	PSKV4E-***	n.a.	n.a.	0,4	0,5	0,5	15
SATELLITE L10T-B	PSKVL E-***	n.a.	n.a.	0,4	0,5	0,5	15
SATELLITE L10t-C, SATELLITE L12t-C	PSKV5E-***	n.a.	n.a.	0,4	0,5	0,5	15
SATELLITE L10W-B	PSKVUE-***	n.a.	n.a.	0,4	0,5	0,5	15
SATELLITE L50-B	PSKT4E-***	0,4	0,4	0,4	5,8	5,8	30
SATELLITE L50-B	PSKT6E-***	0,4	0,4	0,4	5,8	5,8	30
SATELLITE L50-B	PSKTAE-***	0,3	0,3	0,3	4,2	4,2	30
SATELLITE L50-B	PSKTCE-***	0,3	0,3	0,3	4,2	4,2	30
SATELLITE L50-B	PSKTGE-***	0,3	0,3	0,3	3,4	3,4	30
SATELLITE L50-B	PSKTJE-***	0,3	0,3	0,3	3,4	3,4	30
SATELLITE L50-B	PSKTNE-***	0,4	0,4	0,4	3,7	3,7	30
SATELLITE L50-B	PSKTUE-***	0,3	0,3	0,3	4,8	4,8	30
SATELLITE L50-B	PSKTWE-***	0,3	0,3	0,3	4,8	4,8	30
SATELLITE L50-C	PSKWAE-***	0,3	0,3	0,3	4,0	4,0	30
SATELLITE L50-C	PSKWBE-***	0,3	0,3	0,3	4,0	4,0	30
SATELLITE L50-C	PSKWEE-***	0,4	0,4	0,3	3,8	3,8	30
SATELLITE L50-C	PSKWFE-***	0,4	0,4	0,3	3,8	3,8	30
SATELLITE L50-C	PSKWNE-***	0,5	0,5	0,3	4,5	4,5	30
SATELLITE L50-C	PSKWPE-***	0,5	0,5	0,3	4,5	4,5	30
SATELLITE L50-C	PSKWSE-***	0,5	0,5	0,4	3,8	3,8	30
SATELLITE L50-C	PSKWTE-***	0,5	0,5	0,4	3,8	3,8	30
SATELLITE L50-C	PSKWWE-***	0,4	0,4	0,4	5,7	5,7	30
SATELLITE L50-C	PSKWXE-***	0,4	0,4	0,4	5,7	5,7	30
SATELLITE L50-C	PSKXEE-***	0,4	0,4	0,4	3,7	3,7	30
SATELLITE L50-C	PSKXFE-***	0,4	0,4	0,4	3,7	3,7	30
SATELLITE L50D-B	PSKULE-***	0,4	0,4	0,4	5,6	5,6	30
SATELLITE L50D-B	PSKUME-***	0,4	0,4	0,4	5,6	5,6	30
SATELLITE L50D-B	PSKUQE-***	0,3	0,3	0,3	5,6	5,6	30
SATELLITE L50D-C	PSKXJE-***	0,4	0,4	0,3	4,4	4,4	30
SATELLITE L50D-C	PSKXNE-***	0,4	0,4	0,3	4,8	4,8	30
SATELLITE L50D-C	PSKXSE-***	0,5	0,5	0,3	5,9	5,9	30
SATELLITE L50D-C	PSKXWE-***	0,4	0,4	0,3	4,4	4,4	30
SATELLITE L70-C	PSKZAE-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE L70-C	PSKZCE-***	n.a.	n.a.	0,3	0,5	0,5	15

Guidance on how to activate or deactivate wireless network ports	Push "FN" key and the Function key with antenna mark ( "F8" or "F12") at a time
--	---


Model name	Model No. / Part No.	Power Consumption Modes					Time
		standby mode without information /status display	standby mode with information /status display	off mode	networked standby mode	networked standby mode all ports connected/ activated	default time to switch to standby mode
		[Watt]					[Minutes]
SATELLITE L70-C	PSKZEE-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE L70-C	PSKZGE-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE L70-C	PSKZJE-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE P50-B	PSPNUE-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE P50-C	PSPTNE-***	0,5	0,5	0,3	4,5	4,5	30
SATELLITE P50-C	PSPTPE-***	0,5	0,5	0,3	4,5	4,5	30
SATELLITE P50-C	PSPTSE-***	0,5	0,5	0,4	3,8	3,8	30
SATELLITE P50-C	PSPTTE-***	0,5	0,5	0,4	3,8	3,8	30
SATELLITE P50-C	PSPTWE-***	0,4	0,4	0,4	5,7	5,7	30
SATELLITE P50-C	PSPUEE-***	0,4	0,4	0,4	4,4	4,4	30
SATELLITE P50-C	PSPUFE-***	0,4	0,4	0,4	4,4	4,4	30
SATELLITE P50D-C	PSPUAE-***	0,4	0,4	0,3	4,4	4,4	30
SATELLITE P50t-C	PSPTUE-***	0,5	0,5	0,4	3,8	3,8	30
SATELLITE P50t-C	PSPUGE-***	0,4	0,4	0,4	4,4	4,4	30
SATELLITE P70-B	PSPPNE-***	0,4	n.a.	0,4	0,8	0,8	15
SATELLITE PRO A30-C	PT361E-***	0,2	n.a.	0,2	0,8	0,8	15
SATELLITE PRO A30-D	PT381E-***	0,3	n.a.	0,2	0,4	0,4	15
SATELLITE PRO A40-C	PS461E-***	0,2	n.a.	0,2	0,9	0,9	15
SATELLITE PRO A40-D	PS481E-***	0,4	n.a.	0,1	0,4	0,4	15
SATELLITE PRO A50-A	PSSF0E-***	0,2	n.a.	0,2	1,1	1,1	15
SATELLITE PRO A50-A	PSSF2E-***	0,2	n.a.	0,1	1,1	1,1	15
SATELLITE PRO A50-A	PT64NE-***	0,2	n.a.	0,2	0,9	0,9	15
SATELLITE PRO A50-C	PS56AE-***	0,4	n.a.	0,2	0,7	0,7	15
SATELLITE PRO A50-C	PS56CE-***	0,4	n.a.	0,2	0,7	0,7	15
SATELLITE PRO A50-C	PS56JE-***	0,4	n.a.	0,2	0,7	0,7	15
SATELLITE PRO A50-C	PS56LE-***	0,4	n.a.	0,2	0,7	0,7	15
SATELLITE PRO A50-C	PS572E-***	0,2	n.a.	0,1	0,4	0,4	15
SATELLITE PRO A50-C	PS575E-***	0,2	n.a.	0,1	0,4	0,4	15
SATELLITE PRO A50-C	PS576E-***	0,2	n.a.	0,1	0,4	0,4	15
SATELLITE PRO A50-C	PS57DE-***	0,2	n.a.	0,1	0,4	0,4	15
SATELLITE PRO A50-C	PS57EE-***	0,2	n.a.	0,1	0,4	0,4	15
SATELLITE PRO A50-C	PZC54E-***	0,4	n.a.	0,2	0,7	0,7	15
SATELLITE PRO A50-D	PS585E-***	0,3	n.a.	0,2	0,4	0,4	15
SATELLITE PRO A50-D	PS586E-***	n.a.	n.a.	0,2	0,4	0,4	15
SATELLITE PRO A50-E	PS595E-***	n.a.	n.a.	0,2	0,8	n.a.	15
SATELLITE PRO A50-E	PS596E-***	n.a.	n.a.	0,2	0,8	n.a.	15
SATELLITE PRO A50-EC	PT5A1E-***	n.a.	n.a.	0,2	0,7	n.a.	15
SATELLITE PRO A50-EC	PT5A2E-***	n.a.	n.a.	0,2	0,7	n.a.	15
SATELLITE PRO C40-G	PYS26-***	n.a.	n.a.	0,3	0,5	n.a.	15
SATELLITE PRO C40-G	PYS27-***	n.a.	n.a.	0,3	0,5	n.a.	15
SATELLITE PRO C50-G	PYS23-***	n.a.	n.a.	0,3	0,5	n.a.	15
SATELLITE PRO C50-G	PYS24-***	n.a.	n.a.	0,3	0,5	n.a.	15
SATELLITE PRO C70-C	PSCSBE-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE PRO C70-C	PSCSDE-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE PRO C70-C	PSCSFE-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE PRO C70-C	PSCSHE-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE PRO C70-C	PSCSKE-***	n.a.	n.a.	0,3	0,5	0,5	15

Guidance on how to activate or deactivate wireless network ports	Push "FN" key and the Function key with antenna mark ( , "F8" or "F12") at a time
--	---

Model name	Model No. / Part No.	Power Consumption Modes					Time
		standby mode without information /status display	standby mode with information /status display	off mode	networked standby mode	networked standby mode all ports connected/ activated	default time to switch to standby mode
		[Watt]					[Minutes]
SATELLITE PRO C70-C	PSCSME-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE PRO C70-C	PSCSPE-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE PRO C70-C	PSCSRE-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE PRO C70-C	PSCSTE-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE PRO C70-C	PSCSVE-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE PRO NB10-A	PU143E-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE PRO NB10-A	PU144E-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE PRO NB10t-A	PU143E-***	n.a.	n.a.	0,3	0,5	0,5	15
SATELLITE PRO R40-C	PS461E-***	0,2	n.a.	0,2	0,9	0,9	15
SATELLITE PRO R50-B	PSSG0E-***	0,3	n.a.	0,2	0,7	0,7	15
SATELLITE PRO R50-B	PSSG1E-***	0,3	n.a.	0,2	0,7	0,7	15
SATELLITE PRO R50-B	PSSG2E-***	0,3	n.a.	0,2	0,7	0,7	15
SATELLITE PRO R50-B	PSSG3E-***	0,3	n.a.	0,2	0,7	0,7	15
SATELLITE PRO R50-C	PS562E-***	0,4	n.a.	0,2	0,7	0,7	15
SATELLITE PRO R50-C	PS564E-***	0,4	n.a.	0,2	0,7	0,7	15
SATELLITE PRO R50-C	PS576E-***	0,2	n.a.	0,1	0,4	0,4	15
SATELLITE PRO R50-D	PS581E-***	0,3	n.a.	0,2	0,4	0,4	15
SATELLITE PRO R50-E	PS591E-***	n.a.	n.a.	0,2	0,8	n.a.	15
SATELLITE PRO R50-E	PS592E-***	n.a.	n.a.	0,2	0,8	n.a.	15
SATELLITE RADIUS 11 CL10W-C	PSKV6E-***	n.a.	n.a.	0,4	0,5	0,5	15
SATELLITE RADIUS 11 L10W-C	PSKV7E-***	n.a.	n.a.	0,4	0,5	0,5	15
SATELLITE RADIUS 11 L10W-C	PSKVSE-***	n.a.	n.a.	0,4	0,5	0,5	15
SATELLITE RADIUS 14 L40-C	PSLZAE-***	n.a.	n.a.	0,4	0,7	0,7	15
SATELLITE RADIUS 14 L40-C	PSLZBE-***	n.a.	n.a.	0,4	0,7	0,7	15
SATELLITE RADIUS 15 L40DW-C	PSLZDE-***	n.a.	n.a.	0,4	0,7	0,7	15
SATELLITE RADIUS 15 P50W-C	PSPVJE-***	n.a.	n.a.	0,3	0,6	0,6	15
SATELLITE RADIUS 15 P50W-C	PSPVTE-***	n.a.	n.a.	0,3	0,6	0,6	15
SATELLITE RADIUS P20W-C	PSPVVE-***	n.a.	n.a.	0,3	0,0	2,0	15
SATELLITE S50-B	PSPQ2E-***	0,3	0,3	0,3	5,8	5,8	30
SATELLITE S50-B	PSPQ6E-***	0,3	0,3	0,3	4,2	4,2	30
SATELLITE S50-B	PSPQEE-***	0,3	0,3	0,3	3,7	3,7	30
SATELLITE S50-B	PSPRBE-***	0,4	0,4	0,4	4,7	4,7	30
SATELLITE S50-C	PSPVAE-***	n.a.	n.a.	0,3	0,6	0,6	15
SATELLITE S50-C	PSPVEE-***	n.a.	n.a.	0,3	0,6	0,6	15
SATELLITE S50t-C	PSPVCE-***	n.a.	n.a.	0,3	0,6	0,6	15
SATELLITE S50t-C	PSPVGE-***	n.a.	n.a.	0,3	0,6	0,6	15
SATELLITE Z30-A	PT248E-***	0,3	n.a.	0,2	0,7	0,7	15
SATELLITE Z30-B	PT258E-***	0,2	n.a.	0,2	0,7	0,7	15
SATELLITE Z30-C	PT265E-***	0,2	n.a.	0,2	0,8	0,8	15
SATELLITE Z30t-C	PT265E-***	0,2	n.a.	0,2	0,8	0,8	15
SATELLITE PRO R50-E	PS591E-***	n.a.	n.a.	0,2	0,8	0,8	15
SATELLITE PRO A50-E	PS595E-***	n.a.	n.a.	0,2	0,8	0,8	15
TECRA A30-J	PSZ30-***	n.a.	n.a.	0,4	0,9	0,9	15
TECRA A40-C	PS463E-***	0,2	n.a.	0,2	0,9	0,9	15
TECRA A40-C	PS465E-***	0,2	n.a.	0,2	0,9	0,9	15
TECRA A40-D	PS483E-***	0,4	n.a.	0,1	0,4	0,4	15
TECRA A40-D	PS484E-***	n.a.	n.a.	0,1	0,4	n.a.	15

Guidance on how to activate or deactivate wireless network ports	Push "FN" key and the Function key with antenna mark ("F8" or "F12") at a time
--	--

Model name	Model No. / Part No.	Power Consumption Modes					Time
		standby mode without information /status display	standby mode with information /status display	off mode	networked standby mode	networked standby mode all ports connected/ activated	default time to switch to standby mode
		[Watt]					[Minutes]
TECRA A40-D	PS485E-***	0,4	n.a.	0,1	0,4	0,4	15
TECRA A50-A	PT641E-***	0,2	n.a.	0,2	1,1	1,1	15
TECRA A50-A	PT644E-***	0,2	n.a.	0,2	0,9	0,9	15
TECRA A50-A	PT645E-***	0,2	n.a.	0,2	0,9	0,9	15
TECRA A50-A	PT64QE-***	0,2	n.a.	0,2	0,9	0,9	15
TECRA A50-C	PS569E-***	0,4	n.a.	0,2	0,7	0,7	15
TECRA A50-C	PS56DE-***	0,4	n.a.	0,2	0,7	0,7	15
TECRA A50-C	PS56HE-***	0,4	n.a.	0,2	0,7	0,7	15
TECRA A50-C	PS56ME-***	0,4	n.a.	0,2	0,7	0,7	15
TECRA A50-C	PS579E-***	0,2	n.a.	0,1	0,4	0,4	15
TECRA A50-C	PS57BE-***	0,2	n.a.	0,1	0,4	0,4	15
TECRA A50-C	PS57HE-***	0,2	n.a.	0,1	0,4	0,4	15
TECRA A50-C	PS57KE-***	0,2	n.a.	0,1	0,4	0,4	15
TECRA A50-D	PS589E-***	0,3	n.a.	0,2	0,4	0,4	15
TECRA A50-D	PS58BE-***	0,3	n.a.	0,2	0,4	0,4	15
TECRA A50-D	PZC5LE-***	n.a.	n.a.	0,2	0,4	n.a.	15
TECRA A50-E	PS599E-***	n.a.	n.a.	0,2	0,8	0,8	15
TECRA A50-EC	PT5A3E-***	n.a.	n.a.	0,2	0,7	n.a.	15
TECRA C50-B	PSSG6E-***	0,3	n.a.	0,2	0,7	0,7	15
TECRA X40-D	PT472E-***	n.a.	n.a.	0,5	n.a.	n.a.	15
TECRA X40-D	PT474E-***	n.a.	n.a.	0,5	n.a.	n.a.	15
TECRA X40-E	PT481E-***	n.a.	n.a.	0,5	n.a.	n.a.	15
TECRA X40-E	PT482E-***	n.a.	n.a.	0,5	n.a.	n.a.	15
TECRA X40-E	PT484E-***	n.a.	n.a.	0,5	n.a.	n.a.	15
TECRA Z40-A	PT449E-***	0,3	n.a.	0,3	0,7	0,7	15
TECRA Z40-A	PT44FE-***	0,3	n.a.	0,3	0,7	0,7	15
TECRA Z40-A	PT44GE-***	0,3	n.a.	0,3	0,7	0,7	15
TECRA Z40-B	PT454E-***	0,1	n.a.	0,1	0,7	0,7	15
TECRA Z40-B	PT459E-***	0,1	n.a.	0,1	0,7	0,7	15
TECRA Z40-B	PT45FE-***	0,1	n.a.	0,1	0,7	0,7	15
TECRA Z40-B	PT45GE-***	0,1	n.a.	0,1	0,7	0,7	15
TECRA Z40-C	PT461E-***	0,4	n.a.	0,1	0,7	0,7	15
TECRA Z40-C	PT463E-***	0,4	n.a.	0,1	0,7	0,7	15
TECRA Z40-C	PT465E-***	0,4	n.a.	0,1	0,7	0,7	15
TECRA Z40t-A	PT449E-***	0,3	n.a.	0,3	0,7	0,7	15
TECRA Z40t-A	PT44GE-***	0,3	n.a.	0,3	0,7	0,7	15
TECRA Z40t-B	PT45GE-***	0,1	n.a.	0,1	0,7	0,7	15
TECRA Z40t-C	PT463E-***	0,4	n.a.	0,1	0,7	0,7	15
TECRA Z50-C	PT571E-***	0,2	n.a.	0,1	0,4	0,4	15
TECRA Z50-C	PT573E-***	0,2	n.a.	0,1	0,4	0,4	15
TECRA Z50-C	PT577E-***	0,2	n.a.	0,1	0,4	0,4	15
TECRA Z50-D	PT581E-***	0,3	n.a.	0,2	0,4	0,4	15
TECRA Z50-D	PT583E-***	0,3	n.a.	0,2	0,4	0,4	15
TECRA Z50-E	PT591E-***	n.a.	n.a.	0,2	0,8	0,8	15
TECRA Z50-E	PT592E-***	n.a.	n.a.	0,2	0,8	n.a.	15
TECRA Z50-E	PT593E-***	n.a.	n.a.	0,2	0,8	0,8	15
TOSHIBA CB30-B	PLM02E-***	0,2	0,2	0,2	3,4	3,4	30

Guidance on how to activate or deactivate wireless network ports	Push "FN" key and the Function key with antenna mark ( "F8" or "F12") at a time
--	---

Model name	Model No. / Part No.	Power Consumption Modes					Time
		standby mode without information /status display	standby mode with information /status display	off mode	networked standby mode	networked standby mode all ports connected/ activated	default time to switch to standby mode
		[Watt]					[Minutes]
TOSHIBA CB30-B	PLM02E-***	0,2	0,2	0,2	3,4	3,4	30
TOSHIBA CB30-C	PLM03E-***	0,2	0,3	0,2	2,3	2,3	30
TOSHIBA WT12PE-A	PDW0JE-***	0,1	n.a.	0,1	0,3	0,3	15
TOSHIBA WT20-B	PT15CE-***	0,2	n.a.	0,2	1,7	1,7	15
TOSHIBA WT20-B	PT15DE-***	0,2	n.a.	0,2	1,7	1,7	15

* can be digit or character

Disclaimer: All information in this document is provided to the best of Dynabook's knowledge at the time of completion. This declaration is provided for informational purposes only. Dynabook provides this information without warranties of any kind neither expressed nor implied including but not limited to warranties for a particular purpose. Dynabook does not warrant that the content will be error free.